

# 2076 SHAFT SENSOR KIT (1 – 1500 RPM)

## INSTALLATION INSTRUCTIONS

AM-2076



### COMPONENT LIST

PART No.	DESCRIPTION	QTY
AA-110C	COMPACT REED SENSOR	1
AA-117	SHAFT MAGNET & CLAMP	1
AC-205 *	2 WAY 5M EXTENSION CABLE	1
AM-2076	SHAFT SENSOR INSTRUCTIONS	1

*\* NB : This is our generic 5m Extension Cable, For connection to Jackal one end will need to be removed*

### GENERAL INFORMATION

The 2076 Shaft sensor will operate over the range of 1 - 1500 RPM and is used for Shaft RPM monitoring on Ports 1-4 on the FarmscanAG 2200 Surveillance monitor or Ports B1-B6 on the FarmscanAG Jackal.

Alternatively, the 2076 kit may be connected to the Wheel input of any Farmscan Monitor when used on a Drive Shaft for Speed / Area sensing instead of a wheel sensor.



