

# 5002 – 9 Button Button Box

There are five terminals on the Farmscan Button Box. The function of each terminal are as follows :

**1 - Conventional Master**  
ON / OFF

Requires ( + ) Positive voltage above 3v.

**2 - Ground**

Can be chassis earth or linked to a common earth on the controller



## Wiring Instructions

### Conventional -

- Run a wire from the switched side of your master switch to pin 1 on the phoenix plug provided with the button box.
- Run a wire from pin 2 to a common ground.