


■ 1020 Airseeder Head Blockage



■ NO MORE COSTLY UNSOWN STRIPS

Day or night there's no need to continually check your machine. The 1020 monitor warns you before major blockages end up costing you time and money!

The result is much less downtime, faster seeding and complete peace of mind.

The sensors are a proven performer with hundreds of systems in operation. It can pay for itself fast!

■ HOW IT WORKS

Fully sealed impact sensors equipped with bright red LED are bolted to each secondary distribution head.

Sensors are then interconnected on a simple party line cable that runs across the implement, avoiding the need for messy separate wires to each sensor.

As material flows, the sensor listens to the sound level according to sowing rates of seed and fertiliser, all the operator adjusts is the sensitivity control until the cab warning light remains just off - simple as that.


A drop in flowrate or blockage at any secondary head will activate the Red Eye at the sensor causing the cab alarm and warning light to activate.

By switching to Hold, the operator can freeze the system and a quick inspection of all sensors will immediately pinpoint the problem.

The 1020 assists in picking many other problems with airseeders such as fan too slow or not engaged, disconnected and blocked primary hoses, lids not properly shut, empty bins, broken drives etc.

* Optional Low Bin Sensors are available for connection on the party line system to give early warning on low bin levels. (1022 Kit)

TYPICAL LAYOUT



Layout example with head & bin level sensors attached.

**No more costly
unsown strips**
seed faster with complete peace of mind



Order Code		
1020	Airseeder Blockage Monitor Kit - Single Shoot (6 Heads)	
A-1020/3	Air Seeder Monitor	
A-1021	Secondary Head Sensor (x6)	
AC-101	8m Light Duty Power Cable	
AC-1020T	5mt 1020/3 Tractor Cable	
AH-406	Monitor Mounting Bracket - XM	
AH-546	4 Way Junction Box (x1)	
AH-547	3 Way Junction Box (x4)	
AH-548	2 Way Junction Box (x2)	
AH-861	Thumbscrew - 1/4" x 1/2" (x2)	
AP-147	3 Pin Brylite Plug & Socket	
C-003/30	3 Core BLACK/RED/WHITE (30m)	
HG-706	Cable Tie 290mm x 5.0mm (x50)	
HN-3/8	Nut 3/8 "UNC" (x6)	
HS-10X3/4	10G X 3/4 Pan S.Tapper (x2)	
HS-3/876SS	3/8 X 3 UNC Set Screw (x6)	
HW-3/8	Flat Washer 3/8 (x6)	

Order Code		
1020T	Airseeder Blockage Monitor Kit - Twin Shoot (12 Heads)	
	Kit contains as above with the addition of an extra Air Seeder Monitor, extra 4,3,2 way junction boxes, 50m 3 core cable & 12 secondary head sensor.	



Order Code		
1021	Secondary Head Sensor & Junction Box Kit	
A-1021	Secondary head sensor	
AH-547	3 Way junction box, cable ties & screws, copper spacer	



Order Code	SUITS 1020 Monitor ONLY	
1022	Low Bin Level Sensor Kit (185mm)	
A-1022A	Bin Level sensor	
AH-547	3 Way junction box, cable ties & screws	
HG-014	Level sensor seal	



Order Code		
A-1020/3	1020 Airseeder Blockage Replacement Monitor ONLY	



Order Code		
A-1021	Secondary Head Sensor Replacement ONLY	



Order Code		
AH-548	2 Way Junction Box	



Order Code		
AH-547	3 Way Junction Box	



Order Code		
AH-546	4 Way Junction Box	